

Clearing and disinfecting for our radio products

This is JVCKENWOOD recommendation method how to clean and disinfect for our radio products.

[Procedure]

Step1) Remove dust and dirt. (Please use soft cloth. Please use non-metallic brush if the radio was used in harsh environment.)

Step2) Apply 0.5% surfactant (Example: Natural Detergent, Mild Dishwashing Detergent) water solution or 70-80% disinfecting ethanol (*1) to a clean damp soft cloth and clean the radio surface. (Use distilled water recommended.)

Step3) Wipe radio products surface with the soft close.

Step4) Wipe dry with clean soft cloth.

Step5) Make sure solution dry out completely then keep a clean terminals and connectors. And, make sure that no solution remains entrapped near any connectors and terminals cracks or crevices.

*1: Majority of commercially available disinfecting ethanol was diluted 70-80%. Please check dilution ratio before use.

[CAUTION]

We unable to, and did not, determine whether any particular cleaning product is effective in removing specific foreign substances (including viruses) from the device, nor whether any disinfectant will remove all germs or viruses. Please consult the chemical manufacturers' documentation for specifics on cleaning product efficacy with regards to foreign substances (such as viruses).